



## MAG MOUNT WIRELESS CHARGING PAD


### FOREIGN OBJECT DETECTION

Remove phone rings or wallets mounted on device as they will interfere with charging



### LIGHT SENSOR

will automatically enter LED into Night Mode when the room is dark or the sensor is covered



Plug USB cable into an 10W or higher power supply.

### NOTE:

Some USB-A sockets such as laptop's and older power bricks may not have sufficient power for this product and may not be able to charge two devices simultaneously

### LED LIGHT STATES

	DAY MODE	NIGHT MODE
	CHARGER BASE	CHARGER BASE
NO CHARGING		
CHARGING		 LIGHT GOES OFF AFTER 3 SECS
ERROR/ FOREIGN OBJECT DETECTION	 CONTINUAL FLASHING	 CONTINUAL FLASHING